



Fixation

Enlever le capot

Pour enlever le capot, poussez sur l'ergot et soulevez le capot.




Fixation par vis

Fixation sur le mur à l'aide des vis et chevilles fournies.

Fixation par adhésif double-face

Fixation sur le mur à l'aide de l'adhésif double-face fourni. Avant de coller l'adhésif, veillez à bien nettoyer la surface sur laquelle il sera appliqué.




Raccordement

Pour raccorder les fils de commande, faites passer les fils par le chemin de câble prévu à cet effet ou en perçant le trou ❶.

Reportez-vous au paragraphe qui concerne votre type d'installation.

Une fois le raccordement effectué, remettez le capot en place et le courant au disjoncteur.



Raccordement

Bornier version contact sec



Associer le récepteur

Avec un thermostat émetteur

Sur le récepteur, appuyez sur la touche jusqu'à ce que le voyant clignote (~3 secondes). Mettez l'émetteur en mode association (voir sa notice).

vérifiez que la voyant du récepteur ne clignote plus.

Le récepteur est associé à l'émetteur.

Avec un émetteur d'automatisme

Sur le récepteur, appuyez sur la touche jusqu'à ce que le voyant clignote (~3 secondes).

2 choix sont possibles.

Clignotement lent : mode simple allumage.

Clignotement rapide : mode impulsionnel.

Pour passer d'un clignotement à l'autre, appuyez brièvement sur la touche du récepteur.

Sur l'émetteur, envoyez l'information radio d'association (voir sa notice).

Vérifiez que le voyant du récepteur ne clignote plus.

Exemple d'application : avec un détecteur d'ouverture.

Associé au récepteur, le détecteur permet :

- **en automatisme**, de reporter l'état du détecteur (ouvert/fermé),
- **en chauffage**, par exemple en cas d'ouverture d'une fenêtre, de passer le chauffage en hors-gel.

Effacer toutes les associations au récepteur

Maintenez appuyée la touche.

Après 3 secondes, le voyant clignote.

Maintenez l'appui.

Après 10 secondes, le relais s'inverse et le voyant ne clignote plus (mode relais inverseur actif).

Maintenez l'appui.

Après 30 secondes, le voyant clignote (flash), toutes les associations sont effacées.


Relâchez la touche.

Caractéristiques techniques

- Alimentation 230 V, 50 Hz +/-10%,
- Isolement classe II,
- Consommation : 0,5 VA,
- Puissance maximum : 16 A 230 Veff Cos φ =1 ou 300 W max. pour la commande d'éclairage,
- Fréquence radio 868 MHz (Norme EN 300 220),
- Portée radio de 100 à 300 mètres en champ libre, variable selon les équipements associés (portée pouvant être altérée en fonction des conditions d'installation et de l'environnement électromagnétique),
- Nombre d'émetteurs pouvant être associés au récepteur : 8 max.,
- Action automatique : type 1.C (microcoupure),
- Température de fonctionnement : -5°C à +50°C,
- Température de stockage : -10 à +70°C,
- Dimensions : 120 x 54 x 25 mm,
- Indice de protection : IP 44 - IK 04,
- Installation en milieu normalement pollué.





Appareil conforme aux exigences des directives:
R&TTE 1999/5/CE



Mountings

Removing the cover

To remove the cover, push the tab and lift the cover.




Screw-mounting

Mounted on a wall using the screws and pegs supplied.

Mounting by double-sided adhesive tape


Secure using the double-sided adhesive tape supplied. Ensure that the surface on which the tape is applied is thoroughly clean before attaching the tape.



Connection

To connect the control wires, run the wires along the raceway provided or by drilling a hole at ❶.

Refer to the section that deals with your type of installation. When the connection is made, fit the cover and switch on the current at the circuit breaker.



Connection

Dry contact terminal



Associating the receiver

With a transmitter thermostat

Press the receiver button until the LED flashes (~3 seconds).

Put the transmitter into association mode (see transmitter guide).

Check that the receiver LED is no longer flashing.

The receiver is associated with the transmitter.

With a control system transmitter

Press the receiver button until the LED flashes (~3 seconds).

2 possible choices.

Slow flashing: simple lighting mode

Rapid flashing: pulse mode.

Press the receiver button briefly to pass from one rate of flashing to the other.

On the transmitter, send the association radio information (see transmitter guide).

Check that the receiver's LED is no longer flashing.

Application example:

with a door/window magnetic contact.

When associated with the receiver, the magnetic contact can:

- **in control system mode**, report the magnetic contact's status (open/closed),

- **in heating mode**, for instance when there is an open window, switch the heating to frost protection.

Removing all the receiver associations

Press and hold the button.

The LED flashes after 3 seconds. Hold down the button.

The relay reverses after 10 seconds and the LED no longer flashes (reverse current relay mode active).

Hold down the button.

The LED flashes after 30 seconds; all the associations are removed.

Release the button.

Technical characteristics

- 230 V, 50 Hz power supply, +/-10%
- Class II insulation
- Power consumption: 0.5 VA
- Maximum power: 16 A 230 Veff Cos φ =1 or 300 W max. for lighting control
- Radio frequency 868 MHz (standard EN 300 220)
- Radio range 100 to 300 metres outside, variable depending on the associated equipment (the range can be altered depending on the installation conditions and the electromagnetic environment)
- Number of transmitters that may be associated with the receiver: 8 max.
- Automatic action: type 1.C (brownout)
- Operating temperature: -5°C to +50°C
- Storage temperature: -10 to +70°C
- Dimensions: 120 x 54 x 25 mm
- Protection index: IP 44 - IK 04
- Install in an environment with normal pollution levels



Product compliant with directive R&TTE 1999/5/CE